



# LARGE DAMAGED, DEFECTIVE OR RECALLED (DDR) LITHIUM BATTERY RECYCLING KIT

(08-8400HAZ-C2R, CLS379, UN 1A2/X9.3/S)

call2recycle®

Leading the charge for recycling.™

## Contents List



Overpack Box x1



Metal Drum x1



Metal Lid x1



Locking Ring Clamp x1



Bag of CellBlockEX x1



Drum Liner x1



Zip Bags x15



Strip of Tape x1



Zip Tie x1



Instructions x1

## UNPACK & PREPARE

### Step 1: Unpack the overpack box



Carefully open the battery return kit and contents. This box will be used to return your battery.

### Step 2: Install liner & pour base layer



Place provided liner into drum and pour in at least a 1/2-inch deep bed of provided CellBlockEX.

### Step 3: Bag battery or device



Bag and seal into the provided bag.

### Step 4: Place bagged items into can/liner



Bury the bagged battery or device into CellBlockEX, making sure the item is **completely surrounded**.

### Step 5: Fill drum



Pour the remaining CellBlockEX into drum/liner up to the drum rim. Discard any excess CellBlockEX.

## SEAL & SHIP

### Step 6: Seal bag



Pinch and twist the open end of the bag and secure with provided zip tie.

### Step 7: Seal drum



**IMPORTANT:**  
SEE BACK FOR  
SPECIAL INSTRUCTIONS

### Step 8: Pack box



Place sealed drum into overpack box and seal with provided tape.

### Step 9: Secure & ship



Drop at your assigned carrier's local store\* or call for pick-up.  
\*Designated on return label.

- ! **One battery or device per bag.**
- ! **Use zip-style baggies for any additional batteries or devices.**
- ! **Packages containing damaged or defective lithium batteries are forbidden from air transport.**



For questions or assistance, contact customer service at 1.888.224.9764 or [customerservice@call2recycle.ca](mailto:customerservice@call2recycle.ca)

The performance certification of this package requires that it be filled, assembled, and used in full accordance with the instructions herein. The use of substitute components or packing methods, or failure to follow the supplied instructions may result in a package that is not compliant with this certification. Instructions valid

until revoked or superseded. This temporary certificate for transporting damaged, defective, or recalled lithium batteries is offered through the Call2Recycle® program, temporary certificate TU 0660. A copy of this temporary certificate is maintained at [www.call2recycle.ca/certifications](http://www.call2recycle.ca/certifications).

## LARGE DDR KIT: PROPER DRUM SEALING GUIDELINES

(08-8400HAZ-C2R, CLS379, UN 1A2/X9.3/S)

### Required items



Metal Drum x1



Metal Lid x1




Locking Ring Clamp x1

### Step 1: Position lid



Place the metal lid onto the drum's rim with the black side facing up. Press down along the edge of lid to ensure proper alignment.

### Step 2: Open ring clamp



Pull to Open

Before placing the ring clamp, it must be completely open revealing a gap in the ring beneath the leverlock as shown.

### Step 3: Orient ring clamp



Arrows Up

Orient the ring clamp so that the 'UP' arrows on the leverlock are pointing up.

### Step 4: Place ring clamp



With the locking ring fully open, place it (arrow up) around the lip of the lid and release the leverlock from its fully open position.

### Step 5: Lock ring clamp



Ensure that the locking ring is touching the entire edge of the lid and close the lever lock by pulling the lever to the closed position.

### Step 6: Inspect



Inspect to ensure that the lid is evenly seated inside the ring clamp with no gaps, the lock is engaged and the ring is oriented properly.

**For questions or assistance, contact customer service at  
1.888.224.9764 or [customerservice@call2recycle.ca](mailto:customerservice@call2recycle.ca)**